




OLED PROGRAMMING TREE



ALIEN
EDITION



Changing Settings Has Never Been Easier!
To change a setpoint's value, simply use the trigger to scroll to the setpoint you want to change and tap your marker's Power or Eye button to increase or decrease the value.